

OPERATING & SAFETY GUIDE

This appliance is only for professional use by a qualified operator



Small Microwave Oven
Product Code B601024

230v 2.7kw 13amp

A full copy of the EHA Code of Practice regarding the safe hire of Electrical Equipment is available on request

GENERAL SAFETY ADVICE

Mines Leisure Hire will have prepared, checked and delivered this appliance to you in accordance with the Event Hire Association (EHA) Code of Practice for Electrical Testing.

Electrical equipment is required to be properly maintained so as to prevent danger to the user.

It is our policy to inspect every electrical appliance before re-hire. This is done by an electrically qualified person trained in PAT Testing. This combined inspection and test includes:

- Visual Inspection
- Earth continuity tests (for Class I equipment)
- Insulation resistance testing (which can be replaced with protective conductor/touch current measurement)
- Flash Testing (or Hi-Pot testing)
- No load (run) test
- Polarity check (extension or detachable lead sets only), and
- Functional tests

The results of each test are recorded and are kept as records for future inspection.

OPERATING INSTRUCTIONS

This oven has a digital display with buttons to select power and time.

1. Open the door and place food in a suitable container on the tray in the over and close the door.
2. Press POWER key and press the number you would like to set the power to 1 being low and 10 being high.
3. Press TIME key and enter the amount of time you require to cook e.g. 1,3 and 0 will be 1 minute 30 seconds.
4. Press START key – The time on digital display will count down.
5. Remove the food from the oven after the “beep” tone sounds.

Note: If no specific power is entered, the power level will always be maximum.

SAFE USE

The safe use of hire equipment is the sole responsibility for the hirer once the items are collected or arrive on site.

Mines Leisure Hire staff are not allowed to install equipment on site, and you are not permitted to make any alterations to the appliance or its connectors in any way.

If in any doubt please ask a Mines Leisure Hire advisor for advice on 01225 812059 or a qualified electrician.

- Never use the equipment in a poorly ventilated space or near combustible materials.
- Keep all children, animals and bystanders away from the appliances whilst in operation.
- Ensure the floor of the work area is flat, free from trip hazards and non-slip.
- Keep a bucket of water nearby to treat burns.
- Use CO₂ extinguisher to hand in case of and emergency.
- Wear suitable protective clothing, such as an apron, overall and hat. Use kitchen gloves for handling utensils to protect from burns.
- **Allow the appliance to cool fully before touching or cleaning.**